

```

1: //implemented in startup.c
2:  /*
3:   Author: Stefan Mathies
4:   No parameters.
5:   Returns a float corresponding to the distance the user entered on the screen.
6:  */
7:  float getUserDistance();
8:
9:  /*
10:  Author: Emily D'Silva
11:  No parameters.
12:  Initializes and resets sensors, then returns 1 if it succeeded and 0 if it failed.
13:  */
14:  void initializeSensors();
15:
16:
17: //implemented in logger.c
18:  #include "fileLib/PC_FileIO.c" //includes the file library provided by the teaching team
19:
20:  /*
21:  Author: Samuel Mailhot
22:  No parameters.
23:  Creates, then returns, a logfile with the proper name.
24:  */
25:  TFileHandle prepLog();
26:
27:  /*
28:  Author: Kiran Ghanekar
29:  Parameters: int time (the log's timestamp)
30:              string msg (the message to be written)
31:              (optional) float numarg or int numarg
32:                  (a numerical argument to log, may or may not be needed)
33:  No returns. Writes a log message to the file returned by prepLog().
34:  */
35:  void sendLog(TFileHandle &logfile, int &time, string &mesg);
36:  void sendLog(TFileHandle &logfile, int &time, string &mesg, float &numarg);
37:  void sendLog(TFileHandle &logfile, int &time, string &mesg, int &numarg);
38:
39:
40: //implemented in tasks.c
41:  /*
42:  Author: Emily D'Silva
43:  Parameters: float dist (the distance to drive)
44:              bool direction (1 for forward, 0 for backward)
45:              bool toStop (1 to stop at the end, 0 to keep moving)
46:              int speed (between 0 and 100)
47:              float &currentdist (reference to a variable containing
48:                                  how far the robot has advanced)
49:              int &time (reference to an integer corresponding to the current time value)
50:              TFileHandle &logfile (reference to a logfile to write to)
51:  Returns whether the robot was or was not moving after driving 'dist' in 'direction'.
52:  */
53:  bool drive(float dist, bool direction, bool toStop, int speed,
54:            float &currentdist, int &time, TFileHandle &logfile);
55:
56:  /*
57:  Author: Samuel Mailhot
58:  Parameters: int &pastRotations (reference to a variable holding the number of
59:                                  times the lead screw has already turned)
60:              bool spinDown (if true, spin the leadscrew all the way back to 0 rotations)
61:  No returns - rotates the lead screw a certain amount based on

```

```

62:         pastRotations to tension the wheels further.
63:     */
64:     void tensionWheels(int &pastRotations, bool spinDown);
65:
66:     /*
67:     Author: Samuel Mailhot
68:     Parameters: float &currentdist (reference to a variable containing
69:         how far the robot has advanced)
70:         int &time (reference to an integer corresponding to the current time value)
71:         TFileHandle &logfile (reference to a logfile to write to)
72:     Returns 1 if the procedure succeeded, and 0 if it failed.
73:     */
74:     bool clean(float &currentdist, int &time, TFileHandle &logfile);
75:
76:     /*
77:     Author: Stefan Mathies
78:     Parameters: float &currentdist (reference to a variable containing
79:         how far the robot has advanced)
80:         int &time (reference to an integer corresponding to the current time value)
81:         TFileHandle &logfile (reference to a logfile to write to)
82:     No returns - runs the escape procedure in accordance with the flowchart.
83:     */
84:     void escape(float &currentdist, int &time, TFileHandle &logfile);
85:
86:     /*
87:     Author: Stefan Mathies
88:     Parameters: int &pastRotations (reference to a variable holding the number of
89:         times the lead screw has already turned)
90:         int &time (reference to an integer corresponding to the current time value)
91:         TFileHandle &logfile (reference to a logfile to write to)
92:     No returns - runs the shutdown procedure in accordance with the flowchart.
93:     */
94:     void shutdown(int &pastRotations, int &time, TFileHandle &logfile);
95:
96:
97: //implemented in checks.c
98:     /*
99:     Author: Kiran Ghanekar
100:     No parameters.
101:     Returns whether or not a blockage is within range or not.
102:     */
103:     bool ultrasonicDist();
104:
105:     /*
106:     Author: Kiran Ghanekar
107:     Parameters: float &currentdist (reference to a variable holding the distance
108:         moved by the robot since power-on)
109:         float &endpoint (reference to the user-input endpoint)
110:         bool didDrive (whether or not the robot moved, from the accelerometer)
111:         int &failures (reference to a variable containing the number of
112:             health checks that have already failed)
113:         float drivelist (the distance to drive before each health check)
114:         int &time (reference to the current time counter)
115:         TFileHandle &logfile (reference to a logfile to write to)
116:     Returns: 0 if everything passes
117:         1 if the robot should start to leave the pipe
118:         5 if the robot should start cleaning operations
119:         10 if the robot should tension the wheels more
120:     */
121:     int healthCheck(float &currentdist, float &endpoint, bool didDrive, int &failures,
122:         float drivelist, int &time, TFileHandle &logfile);

```